

WQ-JY(I)

Model & performance table



CNP-S-000034

Scan to open this online



Submersible sewage pump, WQ-JY(I) agitating (50 Hz)

Models (45)

Model	kW	rpm	Flow (m3/h)	Head (m)	Weight kg
50WQ9-7-0.55JY(I)	0.55	2850	-	-	20.5
50WQ12-10-0.75JY(I)	0.75	2850	-	-	21.5
50WQ7-15-1.1JY(I)	1.1	2850	-	-	25.5
50WQ15-15-1.5JY(I)	1.5	2880	-	-	33
50WQ15-18-2.2JY(I)	2.2	2880	-	-	37.5
50WQ15-25-3JY(I)	3	2840	-	-	44
50WQ15-32-4JY(I)	4	2840	-	-	49.5
50WQ15-38-5.5JY(I)	5.5	2940	-	-	84
65WQ15-10-1.1JY(I)	1.1	2850	-	-	27
65WQ25-9-1.5JY(I)	1.5	2850	-	-	30
65WQ25-13-2.2JY(I)	2.2	2880	-	-	40.5
65WQ35-9-2.2JY(I)	2.2	2880	-	-	40.5
65WQ25-18-3JY(I)	3	2840	-	-	46
65WQ20-27-4JY(I)	4	2840	-	-	52
65WQ25-30-5.5JY(I)	5.5	2940	-	-	86
80WQ40-10-2.2JY(I)	2.2	2880	-	-	42.5
80WQ35-13-3JY(I)	3	2840	-	-	47
80WQ40-15-4JY(I)	4	2840	-	-	51
80WQ40-22-5.5JY(I)	5.5	2940	-	-	85.5
80WQ40-30-7.5JY(I)	7.5	2940	-	-	92
100WQ50-7-2.2JY(I)	2.2	2880	-	-	48
100WQ50-10-3JY(I)	3	2840	-	-	50
100WQ50-12-4JY(I)	4	2840	-	-	53.5
100WQ75-12-4JY(I)	4	2840	-	-	53.5
100WQ65-15-5.5JY(I)	5.5	2940	-	-	89
100WQ70-18-7.5JY(I)	7.5	2940	-	-	98
100WQ100-15-7.5JY(I)	7.5	2940	-	-	98
150WQ100-10-7.5JY(I)	7.5	2940	-	-	109
150WQ140-10-7.5JY(I)	7.5	2940	-	-	105
65WQ35-50-11JY(I)	11	2930	-	-	98
65WQ30-54-11JY(I)	11	2930	-	-	98
80WQ50-29-11JY(I)	11	2930	-	-	138



Model	kW	rpm	Flow (m3/h)	Head (m)	Weight kg
100WQ100-22-11JY(I)	11	2930	-	-	131
100WQ100-30-15JY(I)	15	2930	-	-	136
100WQ100-35-22JY-4(I)	22	1460	-	-	313
150WQ150-13-11JY-4(I)	11	1440	-	-	219
150WQ140-24-15JY(I)	15	2930	-	-	148
150WQ150-19-15JY-4(I)	15	1440	-	-	240
150WQ200-17-18.5JY-4(I)	18.5	1460	-	-	295
150WQ250-15-18.5JY-4(I)	18.5	1460	-	-	313
150WQ150-25-22JY-4(I)	22	1460	-	-	323
150WQ300-16-22JY-4(I)	22	1460	-	-	326
200WQ210-11-11JY-4(I)	11	1440	-	-	258
200WQ300-11-15JY-4(I)	15	1440	-	-	258
200WQ300-13-18.5JY-4(I)	18.5	1460	-	-	313

Performance is for clean water at 20 C unless stated, as published in the CNP catalogue. The ranges show the first and last points of each performance curve. For a datasheet with the full curve and dimensions, open the model page.